

A

INSTALLATION INSTRUCTION OF THE X-PAD (SHOCK-PAD)

1 The rolls of the X-PAD should be unrolled in the same direction as rolls of grass



2 The X-PAD should be unrolled and matched one roll to another with a distance of 1-2 cm of space between the carpets.



3 The X-PAD does not need to be glued one to the other.

B

ANNOTATIONS

2



The X-PAD is made of polyurethane foam and has an open structure. After placing the mat on a prepared surface, the mat absorbs water or moisture from the air. This will increase the dimensions of the surface by 1-2 cm in comparison to the original size, within the first 24 hours from unrolling.

If the rolls of X-PAD are matched 12-24 hours after unrolling having been in humid conditions, the pad can be matched without allowance.



CAPTION

A, B, - the order of reading the instructions

1, 2, 3, 4, 5, 6 ... - sequence of actions

 - easy operation to perform

 - intermediate activity to be performed

 - activity to be performed with particular accuracy

 - pay attention to the annotations